

FIG. 1

09931570-11901

2/23




FIG. 2

09931570-11501

3/23




FIG. 3

09931570 "11901  
106TT 07EE660

4/23




FIG. 4

FIG. 4

5/23





FIG. 5

09/931,570


6/23

FIG. 6




7/23

FIG. 7



8/23

FIG. 8





9/23




FIG. 9A




FIG. 9B





FIG. 9C

09931570-11901

10/23



Title: Card Interactive Amusement  
Device

Inventor Name: James R. Hornsby et al.

Appln. No.: 09/931,570

11/23




FIG. 11

09931570-11901

12/23




FIG. 12




FIG. 13

09931570-11901




FIG. 14A





FIG. 14B

14/23



\* DEFENSE POSITIONS OF IRIS ARE CONTROLLED BY SWIPING A CARD IN BACK OF BOT. A METAL CONTACT SWITCH NEAR THE DRIVE SHAFT GETS HIT BY A TAB ON DRIVE SHAFT. THIS ACTION WILL MOVE IRIS UP ONE DEFENSIVE POSITION.

\* IT WILL TAKE 6 METAL CONTACT HITS TO MOVE THE IRIS FROM FULLY OPEN TO FULLY OPEN.

\* 1 REVOLUTION OF DRIVE SHAFT CONTACTS SWITCH ONCE.






FIG. 15

09931570-11901

15/23



09931570 11901




FIG. 17

09931570-11501






FIG. 18

09/931,570-11901

18/23




FIG. 19A




FIG. 19B

09931570-119031

19/23




FIG. 20

09/931,570

20/23




FIG. 21

09931570.111901

21/23




FIG. 22

09931570-11501

22/23




FIG. 23

09931570-11901




FIG. 24

09/931,570 "1.1.91  
10511 04511 04511